

FIG.1




FIG.2

Step	Direction		Message
	移動端末	試験装置	
0			
1		←---	PAGING TYPE1(PCCH)
2	--->		RRC CONNECTION REQUEST (CCCH)
3	←---		RRC CONNECTION SETUP (CCCH)
4	--->		RRC CONNECTION SETUP COMPLETE (DCCH)
5	--->		PAGING RESPONSE
6	←---		ACTIVATE RB TEST MODE
7	--->		ACTIVATE RB TEST MODE COMPLETE
8	←---		RADIO BEARER SETUP
9	--->		RADIO BEARER SETUP COMPLETE
10	←---		CLOSE UE TEST LOOP (DCCH)
11	--->		CLOSE UE TEST LOOP COMPLETE
			試験中
12	←---		OPEN UE TEST LOOP
13	--->		OPEN UE TEST LOOP COMPLETE
14	←---		RRC CONNECTION RELEASE
15	--->		RRC CONNECTION RELEASE COMPLETE

FIG.3